LI-ION RECHARGEABLE EASY HANG LANTERN

LIMITED THREE YEAR WARRANTY

EXPRESS WARRANTY

Coleman Brands Pty. Ltd. (“Coleman”) warrants that for a period of three (1) year from the date of original retail purchase, this product will be free from defects in material and workmanship. Coleman will, depending on the circumstances, refund, repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. To the extent permitted by law and subject to your non-excludable rights under the Australian Consumer Law (Schedule 2 to the Competition and Consumer Act 2010 (Cth)) and the New Zealand Consumer Guarantees Act, which are not limited to a one (1) year period, this is your exclusive remedy for any breach of this limited warranty or for any other claims otherwise relating to this limited warranty.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits provided under this warranty are in addition to and do not affect purchaser’s statutory rights under the Australian Consumer Law or other rights at law.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Please keep your proof of purchase documentation, such as the original sales receipt or the relevant credit card statement. Proof of purchase is required to obtain warranty performance. Coleman dealers, Coleman service centres, or retail stores selling Coleman® products do not have the right to alter, modify or in any way change the terms and conditions of this warranty. The warranty is valid only for products that are purchased new and unused in Australia and New Zealand, from Coleman or Coleman dealers or retailers.

WARRANTY EXCLUSIONS AND LIMITATIONS

THE AUSTRALIAN CONSUMER LAW PROVIDES CONSUMERS WITH CERTAIN ‘CONSUMER GUARANTEES’. THESE GUARANTEES APPLY WHERE THE GOODS AND SERVICES COLEMAN SUPPLIES TO YOU ARE OF A KIND ORDINARILY ACQUIRED FOR PERSONAL, DOMESTIC OR HOUSEHOLD USE OR COST LESS THAN $40,000, AND IN THE CASE OF GOODS, ARE NOT RE-SUPPLIED BY YOU. NOTHING IN THIS LIMITED WARRANTY EXCLUDES, RESTRICTS OR MODIFIES RIGHTS WHICH YOU HAVE UNDER THE AUSTRALIAN CONSUMER LAW IN RESPECT OF THE CONSUMER GUARANTEES AND ALL OF THE PROVISIONS IN THIS SECTION ARE TO BE READ SUBJECT TO THE AUSTRALIAN CONSUMER LAW.

This warranty does not cover: (a)normal wear of the product and/or its parts; (b) parts that are not genuine Coleman® parts, consumables, lost parts and accessories; (c) damage resulting from any of the following: negligent use or misuse of the product, commercial use of the product, use contrary to the operating instructions; disassembly, repair or alteration by anyone other than Coleman or Coleman service centre, the use of a part other than a genuine Coleman® part; or (d) acts of God, such as fire, flood, hurricanes and tornadoes.

To the extent permitted by the Australian Consumer Law, the Competition and Consumer Regulation 2010 and the New Zealand Consumer Guarantees Act, Coleman’s liability is limited, depending on the circumstances, to refund, replacement or repair of Coleman® products or components.

For the avoidance of doubt, any and all other warranties or conditions which are not guaranteed by the Australian Consumer Law, the Competition and Consumer Regulation 2010 and the New Zealand Consumer Guarantees Act and which are not expressly included in this warranty as additional warranties or conditions are expressly excluded, including liability for incidental or consequential damages caused by the breach of any express or implied warranty or condition.

MAKING A WARRANTY CLAIM - RETURN TO COLEMAN FOR REPAIR

Take the product to an authorised Coleman retailer or Coleman service centre as soon as the warranty claim arises. You may locate the nearest authorised Coleman retailer or Coleman service centre by visiting www.coleman.com or calling 1800 224 350 or + 61 2 8762 5000. Please ensure that you provide a written description of the problem with the product, together with your contact name, address and telephone number and proof of purchase.

Subject to the applicable consumer laws in your jurisdiction, you must pay for the costs of transporting the product, including packaging, freight and insurance costs, to an authorised Coleman retailer or Coleman service centre for warranty service. If the warranty claim is substantiated and accepted by Coleman, Coleman will at its cost, repair or replace any product or parts and return the product to you. Additionally, if the warranty claim is substantiated and accepted by Coleman, Coleman will reimburse you for the costs of transporting the product to an authorized Coleman retailer or Coleman service centre. Coleman reserves the right to seek reimbursement for any costs and expenses incurred for a warranty claim if the product is found to be in good working order.

If you have any questions regarding this warranty please call 1800 224 350 or + 61 2 8762 5000.

Coleman Brands Pty. Ltd.
ABN 74 091 681 195
Suite W2C1, 75-85 O’Riordan Street,
Sydney Corporate Park, Alexandria, NSW 2015
Australia
Telephone: 1800 224 350 or + 61 2 8762 5000
Email: customerservice@colemanaust.com.au
www.coleman.com

© 2015 The Coleman Company, Inc. All rights reserved.
Coleman®, Coleman® and , are registered trademarks of The Coleman Company, Inc.

4010045386 (ECN20047927-01)

LI-ION RECHARGEABLE EASY HANG LANTERN

How to Use and Enjoy Your Coleman®

LI-ION RECHARGEABLE EASY HANG LED

BATTERY LANTERN

IMPORTANT SAFETY INSTRUCTIONS

WARNING: When using electric appliances, basic precautions should always be followed, including the following:

1. Read all the instructions before using the appliance.
2. To reduce the risk of injury, close supervision is necessary when an appliance is used near children.
3. Only use attachments recommended or sold by the manufacturer.
4. Use only the charger supplied by the manufacturer to recharge.
5. The charger is intended for indoor/household use only. DO NOT USE CHARGER OUTDOORS.
6. To reduce the risk of electrical shock use charger in a dry location. Do not put in water or other liquid. Do not place or store appliance where it can fall or be pulled into a tub or sink.

SAVE THESE INSTRUCTIONS

TO CHARGE BATTERY

Carefully read all instructions before use and save for future reference.

Take the USB cord and adapter out of the bottom by rotating the bottom cover counterclockwise. (Fig. 1)

Plug small end of USB cord into the lantern's charge port (Fig. 2) and the larger end into the adapter. Plug the adapter into an electrical outlet.

- A red indicator LED means the battery is charging.
- A green indicator LED means the battery is fully charged.
- Charge time will take approximately 4 to 6 hours to full charge.

Fig. 1



Fig. 2

TO CHARGE YOUR DEVICE

This lantern has an additional USB Port (Fig.3) for charging small electronic devices like cell Phones / MP3 Players.

Note: Output is 5V DC/ 1 A, not all devices can be charged with this USB Port.



Fig. 3

THINGS YOU SHOULD KNOW

1. Operating time for this lantern depends on whether it is run continuously or intermittently. Intermittent operation extends the runtime of a set of batteries.
2. The LED is a lifetime light source. It will never need to be replaced.
3. Always transport the lantern by the handle located on top of the lantern.
4. To clean the outside of the lantern and globe, use only a damp cloth and mild dishwashing liquid. Avoid excessive water and strong cleaner, which can damage lantern.

Li-Ion

RECHARGEABLE BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.

See recycling information that came with your Coleman® Battery Lantern.